



COUPLER NOTES:

1. For cold weather protection, insulate the inside of the casing with styrofoam insulation, foam rubber, or fiberglass batting in a waterproof bag.
2. Casing and cap material to be PVC Schedule 40 or greater. Pipe to be UV resistant or painted for protection.
3. Compact the backfill around the casing with a hand tamper using 9" lifts evenly around the pipe.
4. Support stake to be a #4 reinforcing rod or similar material. Stake to be fastened to riser pipe with stainless steel hose clamps.